If yes,

- a. Record in Red Book
- b. Discard dairy

If no,

a. Go to the Adjust Individual Dispensing Amounts Task



If dispenser is still out of calibration after second attempt, refer to troubleshooting.

6. Discard Cup

Silver King SKBD3LS Dairy Dispenser: Adjust Individual Dispensing Amounts

Dairy Specification Range (in grams)							
		Min.	Target	Max.			
Coffee	X-Small	13	15	17			
	Small	27	31	34			
	Medium	41	46	51			
	Large	54	61	67			
	X-Large	68	76	84			
Cappuccino	Small	109	122	135			
	Medium	164	183	202			
	Large	219	244	269			
Latte	Small	164	183	202			
	Medium	247	275	303			
	Large	329	367	404			

Milk, cream, and skim have the same target and range.

Dairy Specification Range (in grams)				
COOLATTA [®]				

		Min.	Target	Max.
For Neutral Base	X-Small	41	46	50
	Small	82	91	100
	Medium	123	137	150
	Large	164	182	200

Milk, cream, and skim have the same target and range.

1. Tare Scale with Cup



- Place 1 clean, small hot coffee cup on scale
- Press ON/OFF/ZERO button
- Ensure the display reads in grams **0** α

2. Place cup under proper product tube



3. Go to Calibration Menu

- Go to the calibration menu by selecting the Down arrow once
- The display will read: Calibrate Disp Select Product

4. Select Product

- Select the button of the product you wish to calibrate (milk, cream, or skim) and then select M for medium
 - A medium shot is dispensed

5. Weigh

- Place cup with dairy onto scale
- Note weight on scale

6. Enter Weight

- The display now reads: "Enter Weight 46 grams"
- Press the up or down arrow until the value of on the display matches the weight that was measured using the Ohaus scale
- Press Select



The display again reads: Calibrate Disp Select Product. You may now select the next product to calibrate or press the Home button to return to normal operation.

Silver King SKBD3LS Dairy Dispenser: Adjust Temperature

1. Go to Configure Mode

 On the indicator panel, select the Up or Down arrow until the Config Mode Entr Btn Combo is displayed

2. Adjust Temperature

- Select the X Size button (this is the button combo)
- Press the Up or Down arrow until the term "Temp Set Point" is displayed
- Press the Select button
- Press the Up or Down arrow again to choose the desired temperature (between 35° F – 41° F)
- Press the Select button
- Press the Home button to return to the main menu

3. Verify Temperature



Wait 4–6 hr for the temperature to stabilize before verifying.

Is the dairy temperature within specification of 35 °F-41 °F?