

| | |
|---|---|
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |

- If yes,
 - Record in Red Book, or equivalent
 - Return product to designated hopper
 - Discard cup
- If no, repeat Steps 4–6
- If no after repeating,
 - Return product to designated hopper
 - Go to Adjust Weights task
 - Discard cup

AC 2-GP Sugar Dispenser: Adjust Weights



Weights should always be set to the target for each size. If weights are already set to the target, go to Adjust Volume.

1. Adjust Weights

- Press and hold square button until the display reads “Target Adj”



- Press the size button that needs to be adjusted
 - **Press the star button to increase**
 - **Press the hexagon button to decrease**



Increase



Decrease

- Exit programming mode by pressing and holding square button until you hear 2 beeps



2. Verify New Adjusted Weights

- Go to Check Weights task

3. Is Adjusted Weight Within Specification?

| Sugar Specification (in grams) | | | |
|--------------------------------|------|--------|------|
| Size | Min. | Target | Max. |
| X-Small | 6 | 7 | 9 |
| Small | 13 | 14 | 16 |
| Medium | 18 | 21 | 24 |
| Large | 25 | 28 | 31 |
| X-Large | 33 | 35 | 40 |

| Splenda® Specification (in grams) | |
|-----------------------------------|--------|
| Number of Packets | Target |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |

- If yes,
 - Record in Red Book, or equivalent
 - Return sugar or Splenda® to hopper
- If no,
 - Go to Adjust Volume task

AC 2-GP Sugar Dispenser: Adjust Volume

1. Adjust Volumes

- Press and hold square button until the display reads “Volume Adj”



- Press the size button that needs to be adjusted
 - **Press the star button to increase**
 - **Press the hexagon button to decrease**



Increase



Decrease

- Exit programming mode by pressing and holding square button until you hear 2 beeps



2. Verify New Adjusted Volumes

- Go to Check Weights task
- Make adjustments until within specification

3. Has Adjusted Volume Brought Weight Within Specification?

- If yes,
 - Record in Red Book, or equivalent
 - Return sugar or Splenda® to hopper
- If no,
 - Repeat this task until adjusted volume has brought weight within specification



If unable to get weights within specification after adjusting volume, dispenser should be serviced.