



- b. Place the blender pitcher on the blending area
- c. Press and hold NO SUGAR button until blender pitcher is filled
- d. Discard solution in blender pitcher

6. Purge Sugar Tube

- a. Remove tube from solution
- b. Place the blender pitcher on the blending area
- c. Press and hold NO SUGAR button until steady stream stops
- d. Discard solution in blender pitcher

7. Prime Sugar Tube

- a. Place liquid cane bag back into clean and sanitized liquid cane bag holder
- b. Reconnect tube to bag
- c. Place measuring cup into blender
- d. Press and hold the NO SUGAR button to dispense 5 oz of Liquid Cane Sugar
- e. Discard Liquid Cane Sugar in measuring cup

8. Clean Smallwares

- a. Wash, rinse, sanitize, and air-dry measuring cup and blender pitcher

Island Oasis®: Verify Water Calibration Daily

The Island Oasis Blender can be calibrated using the manual calibration method through the main keypad.

Target Calibration Settings

Function	Minimum	Target	Maximum
Water	3.75 oz (volume)	4 oz (volume)	4.25 oz (volume)

1. Enter Calibration Mode

- a. Hold the STOP button until all numbered LEDs blink

2. Select the Value to be Calibrated

- a. Select #3 button to validate the water calibration value
- b. Place the measuring cup in the Blender
- c. Press the NO SUGAR button

3. Is the Water calibration level within specification?

- If **yes**,
 - a. Press GO button to save
 - b. Press STOP to exit calibration
- If **no**,
 - a. Go to Step 4



If calibrating Liquid Cane Sugar level proceed to Step 2 of: Island Oasis: **Verify Liquid Cane Sugar Calibration Daily**.

4. Adjust water Calibration level

- a. Use the +/- buttons to increase or decrease calibration settings to achieve desired results



Only press +/- one time

5. Repeat Step 2 - 3

Island Oasis®: Verify Liquid Cane Sugar Calibration Daily

The Island Oasis Blender can be calibrated using the manual calibration method through the main keypad.

Target Calibration Settings

Function	Minimum	Target	Maximum
Cane	3.75 oz (volume)	4 oz (volume)	4.25 oz (volume)

1. Enter Calibration Mode

- a. Hold the STOP button until all the numbered LEDs blink

2. Select the Value to be Calibrated

- a. Press recipe #4 button to change the Liquid Sugar Cane calibration value
- b. Place measuring cup in the Blender
- c. Press the NO SUGAR button

3. Is the Cane level in specification?

- If **yes**,
 - a. Press GO button to save
- If **no**,
 - a. Go to Step 4

4. Adjust Cane Calibration level

- a. Use the +/- buttons to increase or decrease calibration settings to achieve desired results



Only press +/- one time

5. Repeat Step 2 - 3

Island Oasis®: Plastic Nozzle Restoration (Rinse Station) As Needed*

*This procedure should only be done as needed to remove soil build-up.

Island Oasis Supplies and Tools



Comet® Cleaner With Bleach



Non-Single Use Container



Jelly Filler Spout Brush

1. Wash Hands and Put on Single-Use Gloves

2. Remove and Dissassemble Nozzle